



**Laundrydri**  
Portable Dryer

## Quick Start Guide



Part Number:  
**DEL089**

[www.ebac.com](http://www.ebac.com)



## BEFORE OPERATION

**Stand your LaundryDri upright for at least 2 hours prior to operating.**

Please ensure all packaging is disposed of or stored safely where it will not be a danger to children or pets.

Open the water container door, remove the water container - replace and close the door. This will reset the sensors which may have been activated during transit.

## GETTING THE MOST OUT OF YOUR EBAC LAUNDRYDRI

### Choosing Your Drying Setting: EcoDri vs. MaxDri

LaundryDri comes with a variable drying setting designed to suit different needs:

#### EcoDri

Use this setting when you simply want to reduce the excess moisture that builds up when drying clothes indoors. It's energy-efficient and perfect for everyday use.

#### MaxDri

Need a faster drying boost? Turn the dial to MaxDri.

Ensure the unit is positioned on a flat even surface.

## POSITIONING YOUR EBAC LAUNDRYDRI

To get the best results from your LaundryDri, where you place it really matters.

Got a laundry room? Or small unused room? Great! That's the ideal spot - drying is faster and more contained.

No laundry room? No problem. Just set up your LaundryDri in a central area close to where you usually dry your clothes. This keeps things convenient and efficient.

### Key setup tips:

**Stay close:** Position LaundryDri within **2 metres of your wet clothes** for optimal drying.


**Use a clothes horse or drying rack:** Make sure your clothes are hung with enough space between them so air can circulate freely.

**Using a drying tent?** Place LaundryDri with the **back of the unit facing the tent's open hole**, and keep it fairly close to the opening to ensure the unit is pulling moisture from inside the tent.

With the right setup, you'll be drying smarter in no time.

Place the LaundryDri away from direct heat source. As the unit uses a cold surface to collect moisture, direct heat will reduce its ability to do so.

## SETTINGS & CONTROLS



### 1 Operation Indicator Light

**Amber** - the unit is operating.

**Green** - the unit has collected all moisture. (If your clothes still feel slightly damp turn the Drying Dial up to continue drying.)

**Red** - the water container is full.

When you are first setting your unit please make sure the dryer comes on within a few minutes, if it doesn't simply turn the Drying Dial to a higher setting.

### 2 Fan Speed

- **EcoDri** - energy-efficient and perfect for everyday use.
- **MaxDri** - for a faster drying boost.

### 3 Drying Dial

#### Low Setting

To stop the unit collecting moisture, turn this dial all the way to the left.

#### Mid Settings

Ideal for lightly damp clothes or delicate items that just need a touch of drying.

#### Higher Settings

Perfect for heavy loads or when you want your laundry extra dry — like towels or bedding.

Think of this dial like your personal dryness preference — turn it up if you want the machine to keep going until things are super dry, or keep it low for a gentle, shorter cycle.

## TECHNICAL SAFETY INFORMATION

**Min Operating Temperature 3C**

**Max Operating Temperature 35C**

**Fuse Rating 13A**

- Do not use the machine if the power cord or cabinet are damaged.
- If the machine is damaged or in need of repair please contact Ebac.
- Do not poke objects into any grilles on the machine.
- This machine complies with EMC/RFI directive EN60555 (BS800).
- Ebac has a policy of constant development and, therefore, reserves the right to change specifications without prior notice.
- Do not use the machine without the permanent drainage bung in place on the back of the machine.
- Your LaundryDri should not be located in such a way that it will become an obstacle or hazard.
- Your LaundryDri should not be placed directly at the top of the stairs.
- To protect against electrical shocks, do not immerse unit, plug or cord in water, or spray with liquids.
- Ebac would always recommend plugging the appliance directly into the mains where possible however an extension lead may be used if required. The extension lead should be rated at the correct current for the appliance, fuse protected and electrically safe. The extension must not be overloaded. It is the responsibility of the user to ensure all of these conditions are met. Ebac won't accept responsibility for malfunction due to the use of an extension.
- Ensure Power supply is RCD protected at 30mA.
- Do not put the unit close to heat-generating devices or near flammable and dangerous materials. (e.g. electrical fires, fireplaces, etc.)

**Please note:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have supervision or have been given instruction concerning the use of the appliance in a safe way, and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

**WARNING! THIS PRODUCT CONTAINS R290 FLAMMABLE REFRIGERANT GAS.  
READ THE SPECIFIC WARNINGS ON THE NEXT PAGE.**

## WARNINGS FOR USING R290 REFRIGERANT ONLY

**This appliance contains R290 gas (A3 flammability classification).**

- Do not use any means to accelerate the defrosting process.
- When cleaning the appliance this should be limited to the exterior panels and filter, following the guidelines within this manual. If the appliance is installed, used or stored in an unventilated room, the room must be such as to prevent stagnation of possible leaks of refrigerant gas as there could be a danger of fire or explosion should the refrigerant come into contact with electric heaters, stoves or other sources of ignition.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation. (4m<sup>2</sup> - this equates to a 2 meter by 2 meter room)
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that the refrigerants may not contain an odour.
- Appliance should be installed, operated and stored in a room with a floor area larger than 4m<sup>2</sup> (this equates to a 2 meter by 2 meter room).
- This appliance contains ≤90g of R290 refrigerant gas
- R290 is a refrigerant gas that complies with the European directives on the environment.
- Do not puncture any part of the refrigerant circuit.
- Compliance with national gas regulations shall be observed.
- Keep ventilation openings clear of obstruction.
- The appliance shall be stored so as to prevent mechanical damage from occurring.



### CAUTION

Risk of fire/flammable materials (required for R290 units only).



### IMPORTANT NOTICE

Read this manual carefully before installing or operating your new dehumidifier unit. Make sure to save this safety warning for future use.

## EXPLANATION OF SYMBOLS DISPLAYED ON THE UNIT



### WARNING

This symbol shows that this appliance uses a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.



### CAUTION

This symbol shows that the operation manual should be read carefully.



### CAUTION

This symbol shows that the service personnel should be handling this equipment with reference to the installation manual.



### CAUTION

This symbol shows that information is available such as the operating manual or installation manual.

## WARRANTY

If you bought directly from us at Ebac we have already activated your warranty for you.

If you bought from one of our approved retailers you'll need to activate your warranty as soon as possible.

You'll need your serial number which can be found on the box your LaundryDri arrived in or on the inside of the machine, behind the water container.

To activate simply scan this QR code on the front of this manual or visit [ebac.com/support/warranty](https://ebac.com/support/warranty)

## LEAVE US A REVIEW

Scan the QR code to leave us a review!



## CUSTOMER SERVICE

We are always happy to help with any questions or queries you may have.

[customer.services@ebac.com](mailto:customer.services@ebac.com)

**0345 805 0000**

Monday-Friday 9am-5pm



[www.ebac.com](https://www.ebac.com)